


David J. Folkes, PE EnviroGroup Limited


EPA National Forum on Vapor Intrusion: Science, Technology and Policy Philadelphia, PA January 12-13, 2009


Outline


- Mitigation concepts
- New Developments
 - Barriers
 - Venting
 - Depressurization
 - Sustainable systems


No specific product endorsements are intended by this presentation.




















Key Mitigation Points

- Understand how the subsurface will respond to mitigation features
- Understand the difference between barriers, venting, and depressurization
- Do it well


Barrier Concepts

- Concentrations build up below barrier
 - Concentration gradient flatter
 - Diffusion flux slower
 - Vapors diffuse laterally
- Key concepts
 - Barrier thickness/integrity
 - Composite barriers enhance performance
 - Venting layers may decrease performance unless well ventilated or depressurized

New Developments - Barriers

 Thick (e.g. 60 mil) asphaltic spray-on barriers have been available for many

years



Courtesy Liquid Boot®


New Developments - Barriers

 New barrier products include an HDPE and spray-on asphalt
 Geo-Seal™

Provided courtesy of Land Science Technologies

New Developments - Barriers

- Composite spray-on barrier (Geo-Seal)
 - HDPE provides chemical resistance
 - 15 mil HDPE above & below asphalt core
 - Asphalt core allows thinner, flexible HDPE
 - Breaches in membrane "sealed" by asphalt



Courtesy Land Science Technologies

Venting Concepts

- Air movement through venting layer <u>dilutes</u> concentrations below slab
- Venting layer is not necessarily depressurized
 - Stack effect can still pull sub-slab vapors into building
- Venting relies on sufficient dilution to reduce sub-slab concentrations
- Generally applicable when vapor concentrations only modestly elevated
- Venting efficiency/rate is the key

New Developments in Venting*New to U.S.

Aerated floor systems


- Allow highly efficient movement of air through **CUPOLEX® BUILDING SYSTEMS**

voids in slab

Dome-shaped polypropylene forms below concrete create inter-connected void system.

vent

Cupolex ® Aerated Floor System



Cupolex ® Aerated Floor System

Aerated floor systems



CUPOLEX ® forms and vent pipes in place prior to pouring concrete slab.


Separations in forms create grade beams in slab.

Aerated Floors on Existing Floors

Cupolex Windi®

- Aerated floor sub-base
- Concrete poured on top of forms
- Void space vented
- Can be attached to walls





Venting of Aerated Floors

 Air moves through voids more efficiently than gravel



From Ove Arup, Sept 1997




Figure 4 Result of CFD Modelling: Volume Flow Rate vs Wind Speed for 5m x 5m Foundation

Passive Venting of Aerated Floors

Thermal gradients

Warm


AFS

Sub-slab ventilation

Air flow direction reverses in summer

Cupolex ® Passive Venting Design


Thermal gradients



Direct air flow through AFS


Results of modeling study by Ove Arup 1997





Geosynthetic venting media


Geogrids and geotextiles



Courtesy Liquid Boot®

Geosynthetic venting media


Typically placed in strips



Courtesy Liquid Boot®

Geosynthetic venting media

Vents typically placed in gravel




New Developments in SSD

- Basic "radon" system technology mature
- Generally very reliable if done well
- Works even when concentrations high
- Enhancements
 - Improved barriers (extend suction field)
 - Aerated floor systems (extend suction field)


Sustainable Mitigation

The future - more emphasis on reduced energy requirements

Passive systems



Wind turbine



Photos courtesy Pontarolo Engineering

Sustainable Mitigation

- The future more emphasis on reduced energy requirements
 - Intermittent fan operation based on:
 - Pressure differential monitoring
 - Tied to operation of building exhaust fans
 - Tied to building occupancy
 - Real time concentration monitoring?

Information Resources

- www.envirogroup.com
 - Links to state and federal VI guidance
 - Download VI technical papers
 - Vapor Intrusion Newsletter (free)

- Questions?
 - dfolkes@envirogroup.com
 - -303-790-1340 ext. 111